

Rope and steel come together in the perfect and original pairing that distinguishes Vetta, the leisure chair. The tubular frame folds over with the ease of the rope that emerges as its ideal extension and then comes full circle, hooking up at the bottom. Thanks to the slotting device at the end of the frame, the back can be set in two different positions for ease and comfort.



### Description

Code: **171** 

Typology: Deck Chairs

Collection: Vetta

Folding: Yes Reclining: Yes Static Load: 200 Kg Back Cushion: Yes

Cushion Material: Emu-Tex

Technical Info



Width: 78 cm Depth: **104-110 cm** Height: 80-90 cm Weight: 7.70 Kg Static Load: 200 Kg Packaging

Packages: 1 Pieces for pack: 1

Dimensions: 140x20x77 cm

Phone: +39 075 874021 / +39 075 8743903

Volume: **0.215 mc** 

Polyethylene bag and cardboard

box

E-mail: info@emu.it




### Colors





32

24



Phone: +39 075 874021 / +39 075 8743903

E-mail: info@emu.it

Dark Blue - Navy Blue - Light Grey

300/81

300/83 33 Corten - Rust - Tobacco

31



#### Materials

#### **Emu-tex**

It is a technical fabric for outdoor use made with polyvinyl chloride thread. It features exceptional strength to ensure durability: maximum resistance to UV rays, the elements, humidity and sudden changes in temperature.

**Maintenance:** Avoid prolonged contact with greasy substances and/or dyes, which may be absorbed by the coating material, causing permanent staining and deterioration of the yarn structure. Frequent washing: use water and non-abrasive, colourless liquid detergents with neutral PH. Leave the detergent to react for a few minutes, if required Rinse thoroughly with water at a temperature not exceeding 30°C. If pressurised devices are used, keep the diffuser tip at least 60/70 cm away from the surface of the item. Repeat the operation if necessary. Periodic and/or extraordinary washing: use a regenerating stain remover for PVC, following the procedure below. Operations to be performed:

- apply the stain remover to the dirty fabric;
- allow the product to act for 15-30 minutes;
- rub the stained area using a common hard-bristle laundry brush (phase is necessary since the dirt is inside the weaving);
- rinse with running water (if possible rinse using a high-pressure cleaner, remaining at a distance of approx. 60 cm so as not to damage the fabric with the high pressure);
- repeat the operations if necessary.

Note: when applying the product, pay attention not to apply it to the painted parts of the product.

#### Steel

Iron and carbon alloy, with carbon content below 2%, treated to withstand the elements with the unique EMU-Coat anti-corrosio process.

**Maintenance:** Avoid prolonged contact with greasy substances and/or dyes, which may be absorbed by the coating material, causing permanent staining and deterioration of the yarn structure. Frequent washing: use water and non-abrasive, colourless liquid detergents with neutral PH. Leave the detergent to react for a few minutes, if required Rinse thoroughly with water at a temperature not exceeding 30°C. If pressurised devices are used, keep the diffuser tip at least 60/70 cm away from the surface of the item. Repeat the operation if necessary. Periodic and/or extraordinary washing: use a regenerating stain remover for PVC, following the procedure below. Operations to be performed:

- apply the stain remover to the dirty fabric;
- allow the product to act for 15-30 minutes;
- rub the stained area using a common hard-bristle laundry brush (phase is necessary since the dirt is inside the weaving);
- rinse with running water (if possible rinse using a high-pressure cleaner, remaining at a distance of approx. 60 cm so as not to damage the fabric with the high pressure);
- repeat the operations if necessary.

Note: when applying the product, pay attention not to apply it to the painted parts of the product. To keep the product in good condition for a long time, we recommend storing it indoors and in a dry place during the winter to prevent condensate from forming. Before the winter and on a quarterly basis, if the products are kept near the sea, it is recommended to clean the metal surfaces with a soft cloth using water or detergent and protect them with Vaseline oil or car wax.



#### **Synthetic Rope**

Double braid with polyester or Nylon core and multifilament propylene covering. The external fibre is waterproof and resistant to UV rays.

**Maintenance:** Avoid prolonged contact with greasy substances and/or dyes, which may be absorbed by the coating material, causing permanent staining and deterioration of the yarn structure. Frequent washing: use water and non-abrasive, colourless liquid detergents with neutral PH. Leave the detergent to react for a few minutes, if required Rinse thoroughly with water at a temperature not exceeding 30°C. If pressurised devices are used, keep the diffuser tip at least 60/70 cm away from the surface of the item. Repeat the operation if necessary. Periodic and/or extraordinary washing: use a regenerating stain remover for PVC, following the procedure below. Operations to be performed:

- apply the stain remover to the dirty fabric;
- allow the product to act for 15-30 minutes;
- rub the stained area using a common hard-bristle laundry brush (phase is necessary since the dirt is inside the weaving);
- rinse with running water (if possible rinse using a high-pressure cleaner, remaining at a distance of approx. 60 cm so as not to damage the fabric with the high pressure);
- repeat the operations if necessary.

Note: when applying the product, pay attention not to apply it to the painted parts of the product. To keep the product in good condition for a long time, we recommend storing it indoors and in a dry place during the winter to prevent condensate from forming. Before the winter and on a quarterly basis, if the products are kept near the sea, it is recommended to clean the metal surfaces with a soft cloth using water or detergent and protect them with Vaseline oil or car wax. Clean using a mild detergent product and soft cloth.

#### **Cushion Material**

#### **Emu-Tex**

It is a technical fabric for outdoor use made with polyvinyl chloride thread. It features exceptional strength to ensure durability: maximum resistance to UV rays, the elements, humidity and sudden changes in temperature.

**Maintenance:** Avoid prolonged contact with greasy substances and/or dyes, which may be absorbed by the coating material, causing permanent staining and deterioration of the yarn structure. Frequent washing: use water and non-abrasive, colourless liquid detergents with neutral PH. Leave the detergent to react for a few minutes, if required Rinse thoroughly with water at a temperature not exceeding 30°C. If pressurised devices are used, keep the diffuser tip at least 60/70 cm away from the surface of the item. Repeat the operation if necessary. Periodic and/or extraordinary washing: use a regenerating stain remover for PVC, following the procedure below. Operations to be performed:

- apply the stain remover to the dirty fabric;
- allow the product to act for 15-30 minutes;
- rub the stained area using a common hard-bristle laundry brush (phase is necessary since the dirt is inside the weaving);
- rinse with running water (if possible rinse using a high-pressure cleaner, remaining at a distance of approx. 60 cm so as not to damage the fabric with the high pressure);
- repeat the operations if necessary.



Note: when applying the product, pay attention not to apply it to the painted parts of the product. To keep the product in good condition for a long time, we recommend storing it indoors and in a dry place during the winter to prevent condensate from forming. Before the winter and on a quarterly basis, if the products are kept near the sea, it is recommended to clean the metal surfaces with a soft cloth using water or detergent and protect them with Vaseline oil or car wax. Clean using a mild detergent product and soft cloth. Evitare il contatto prolungato con sostanze grasse e/o coloranti che potrebbero venire assorbite dal materiale di rivestimento e dare luogo a macchie permanenti, oltre che deteriorare la struttura del filato. Lavaggi frequenti: utilizzare acqua e detergenti liquidi non abrasivi con PH neutro e incolori. Eventualmente lasciare agire il detergente alcuni minuti. Sciacquare abbondantemente con acqua a temperatura non superiore a 30°C. Nel caso di utilizzo di dispositivi a pressione, tenere la punta del diffusore ad una distanza di almeno 60/70 cm dalla superficie del manufatto. Se necessario ripetere l'operazione. Lavaggi periodici e/o straordinari: utilizzare uno smacchiatore rigenerante per PVC, secondo la procedura seguente.

Operazioni da eseguire:

- applicare lo smacchiatore al telo sporco;
- far agire il prodotto per 15-30 minuti;
- strofinare le zone macchiate con comune spazzola da bucato a setole dure (fase è necessaria poiché lo sporco è all'interno della tessitura);
- risciacquare con acqua corrente (se possibile risciacquare con pulitrice a pressione mantenendo una distanza di circa 60 cm per non danneggiare il telo con l'alta pressione);
- se necessario ripetere le operazioni.

Note: durante l'applicazione del prodotto fate attenzione a non applicarlo nella parti verniciate del prodotto.